

Add Master Card and User Card Instructions

RFID Locks

For full fitting, operation and
programming instructions please visit
www.lowe-and-fletcher.co.uk

Lowe & Fletcher Ltd (UK)

Moorcroft Drive, Wednesbury, West Midlands

WS10 7DE, England

T: +44 (0) 121 505 0400

F: +44 (0) 121 505 0420

E: sales@lowe-and-fletcher.co.uk

W: www.lowe-and-fletcher.co.uk

Add Master Card

Press logo button



Either present
your current
master card to
the lock

OR

Enter your
current master
code using the
keypad

Press 01 using
the keypad


Present new
master card



NOTE: Any previously added
Master Cards will be deleted

Add User Card

Press logo button



Either present
your master card
to the lock

OR

Enter your
current master
code

Press 02

Present user card



NOTE: Any previously added
User Cards will be deleted